

FTC SECURITY CAMERAS GUIDE



SPECO BLUE MOBILE APP

How to Share Cameras

1. Open the **Speco Blue** app and sign in to your account.
2. Tap **Server List** to view your added devices, sites, or cameras.
3. Select the **Share** icon next to the recorder, site, or camera you want to share.
4. Enter the **email address** associated with the recipient's Speco Blue account.
5. Choose the **access level** you want to allow (for example, Live View only or Live View + Playback).
6. Tap **Finish or Share** to send the invitation.

The recipient must open their Speco Blue app and navigate to:

Server List → Settings → Sharing Manager → Shared by Others, then accept the shared camera/site.

Important: The person you are sharing with must have the Speco Blue app installed and be registered as a user before sharing access.

Viewing Recorded Footage


1. Open the **Speco Blue** app and select a camera to enter **Live View**.
2. Tap the **Playback** icon (film reel with a play symbol), typically located in the bottom-right corner.
3. The **Remote Playback** screen will appear, showing:
 - a. A **timeline** of recorded video
 - i. **Blue** = continuous recording
 - ii. **Orange** = motion-detected events
 - b. A **date selector** below the timeline
4. Swipe left or right on the **timeline** to move to different times of the day.
5. Use the on-screen **playback controls** (play, pause, rewind, fast-forward) to review footage.

Tips for Playback

- Tap the **calendar icon** to quickly jump to a different date.
- If your system has multiple cameras, you can switch cameras directly from the **playback screen**.
- To **save a video clip**, tap the scissors + play icon, select the desired time range, and export the clip to your device.

Important Reminder

- After **any power outage**, always **check and correct** the time and date settings on your camera system.



Speco Blue

